

Parts List for Puloon LCDM-2000 .




SENSIS Kiosk Components
+7 (495) 657-8-555

8-800-333-50-12
ask@sensis.ru

www.sensis.ru




Parts List for Puloon LCDM-2000



Part code:	Parts list
B2803A0157	(A) SHAFT ASS'Y PICK-UP ROLLER
B2803A0156	(B) SHAFT ASS'Y FEED ROLLER
B2803A0158	(C) SHAFT ASS'Y ONEWAY ROLLER
B2803A0150	(D) SHAFT ASS'Y CASH FEED 1
B2803A0151	(E) SHAFT ASS'Y CASH FEED 2
B2803A0152	(F) SHAFT ASS'Y CASH FEED 3
B2803A0153	(G) SHAFT ASS'Y CASH FEED 4
B2803A0154	(H) SHAFT ASS'Y CASH FEED 5
B2803A0155	(I) SHAFT ASS'Y CASH FEED 6
B2803A0155	(J) SHAFT ASS'Y CASH FEED 6
B2803A0155	(K) SHAFT ASS'Y CASH FEED 6
B1604P0082	(L) GUIDE CASH FEED 1
	(M) GUIDE CASH FEED 2 LCDM-2000
	(N) GUIDE CASH FEED 3 ASS'Y
B1604P0088	(O) GUIDE CASH FEED 5 ASS'Y
B1604P0087	(P) GUIDE CASH FEED 6 ASS'Y
B1604P0089	(Q) GUIDE CASH FEED 7 ASS'Y
	(R) SHAFT ASS'Y CASH FEED 8
B1604P0085	(S) GUIDE CASH FEED 2 ASS'Y
	(T) GUIDE PRESS 2 ASS'Y
	(U) SHAFT ASS'Y CASH FEED 7
	(V) GUIDE PRESS 1 ASS'Y


GUIDE PRESS 2 / (T)

Part code:



GUIDE PRESS 1 / (V)

Part code:



Parts List for Puloon LCDM-2000

PICK-UP ROLLER (A)

Part code: B2803A0157



FEED ROLLER (B)

Part code: B2803A0156



ONEWAY ROLLER (C)

Part code: B2803A0158



CASH FEED 1 (D)

Part code: B2803A0150



GUIDE CASH FEED 1 / (L)

Part code: B1604P0082



CASH FEED 5 / (H)

Part code: B2803A0154

CASH FEED 4 / (g)

Part code: B2803A0153

CASH FEED 6 / (K) = (J) = (i)

Part code: B2803A0155

CASH FEED 3 / (F)

Part code: B2803A0152

CASH FEED 2 / (E)-

a little shorter by 3 mm(G)

Part code: B2803A0151



GUIDE CASH FEED 2 / (M)



GUIDE CASH FEED 3 / (N)



CASH FEED 5 / (O) Part code: B1604P0088



GUIDE CASH FEED 6 / (P) Part code: B1604P0087



CASH FEED 7 / (Q) Part code: B1604P0089



FEED ROLLER8 / (R1) ROLLER FEED CROWN (¢ 18)




Направляющая 2 / (S) Part code: B1604P0085



CASH FEED 7 / (U) ROLLER FEED CROWN



Parts List for Puloon LCDM-2000



Part code:	Parts list:
4470-E0681A	(G1) / GEAR FEED (Z:27, M:1)
4470-E0621A	(G2) / GEAR DFDM DRIVE (Z:27, M:1)
B2505P0018	(P1) / PULLEY MOTOR (XL16, ϕ 8)
	(P2) / PULLEY CASH FEED 1
4560-E0301A	(P3) / PULLEY CASH FEED 2
B2505P0020	(P4) / PULLEY FEED (XL15, ϕ 8)
B2505P0019	(P5) / PULLEY FEED (XL20, ϕ 8)
	(P6) / PULLEY DRV MXL17
	(P7) / PULLEY REVERSE (MXL42, ϕ 8)
B1104P0021	(T1) / BELT TIMING 108XL(W=6.4)
B1104P0022	(T2) / BELT TIMING 140XL(W=6.4)
B1104P0021	(T3) / BELT TIMING 108XL(W=6.4)
B1104P0016	(T4) / BELT TIMING 56MXL(W=3.2)
	(T5) / BELT TIMMING 56XL(W=6.4)
	(T6) / BELT TIMING 166XL(W=6.4)
B1104P0026	(F1) / BELT FEEDING PS197 (W=10)
B1104P0025	(F2) / BELT FEEDING PS140 (W=10)
	FEED(ϕ 18)(R1)/ROLLER FEED CROWN(ϕ 18)
	(R2) / ROLLER IDLE CROWN (ϕ 18)
	(R3)/ROLLER IDLE CROWN(ϕ 16)
R1205P0002/B1205P0002	CLUTCH E3637RH24P DONGYANG LCDM UPR/LWR
B2203P0070	MOTOR BLDC DR-5238-018 SHINANO
	GEAR FEED (P8)

CLUTCH

Part code: R1205P0002



MOTOR

Part code: B2203P0070



Parts List for Puloon LCDM-2000

GEAR FEED (G1)

Part code: 4470-E0681A



GEAR DFDM DRIVE (G2)

Part code: 4470-E0621A



PULLEY MOTOR (P1)

Part code: B2505P0018



PULLEY CASH FEED 1 (P2)

Part code:



PULLEY CASH FEED 2 (P3)

Part code: 4560-E0301A



PULLEY FEED (P4)

Part code: B2505P0020



PULLEY FEED (P5)

Part code: B2505P0019



PULLEY DRV (P6)

Part code:



PULLEY REVERSE (P7)

Part code:



GEAR FEED (P8)

Part code:



BELT TIMING(T1) = (T3)

Part code: B1104P0021



BELT TIMING (T2)

Part code: B1104P0022



BELT TIMING (T4)

Part code: B1104P0016



BELT TIMING (T5)

Part code:



BELT TIMING (T6)

Part code:



BELT FEEDING (F1)

Part code: B1104P0026



BELT FEEDING (F2)

Part code: B1104P0025



ROLLER FEED CROW ϕ 18(R1)

Part code: B1104P0025



ROLLER IDLE CROWN ϕ 18

(R2)



ROLLER IDLE CROWN ϕ 16

(R3)



(GUIDE CASH FEED 2 ASS'Y(LOWER)) / (B1604P0085).



Part Code:	Parts List and Quantity	
B1604P0085	GUIDE CASH FEED 2	1
B1108P0085	Mount	2
B2701A0040	Roller (white)	2
B2803P0132	Shaft	2
B1108P0040	Mount	8
R-1030ZZ	Bearing	4
B2803P0131	Shaft	8
B2702P0029	Roller	4
B2810P0021	Spring	12
B2810P0020	Spring	8
	Skrew M2.6x6	20

GUIDE CASH FEED

Part Code: B1108P0085



Roller (white)

Part Code: B2701A0040



Shaft

Part Code: B2803P0132



Mount

Part Code: B1108P0040



Bearing

Part Code: R-1030ZZ



Shaft

Part Code: B2803P0131



Roller

Part Code: B2702P0029



Spring

Part Code: B2810P0021



Spring

Part Code: B2810P0020



(GUIDE CASH FEED 7 ASS'Y) / (B1604A0244).



Part Code:	Parts List and Quantity	
B1604P0089	GUIDECASHFEED7ASS'Y)	1
B1108P0085	Mount	10
B2702A0040	Roller	10
B2803P0132	Shaft	10
B2810P0021	Spring	20
	Skrew M2.6x6	20
B2803P0129	HAFTHINGEGUIDE	1
B2803P0128	HAFTGUIDELOCK	1
B2810P0030	Upper Shaft Springs B2803P0128)	2
RPA000007B / APA000007B	Sensor Touch CVJ45(PWASENSORRCV)	2
	SkrewM3x6	2
B1212A0022	CABLE SENSOR RCV EJT/EMIT (J5)	1
	LABEL LCDM-1000	1
	Clap (E-RING 4(BK))	2
B2810P0019	SPRING TENSION MICR	4

Mount

Part Code: B1108P0085



Part Code: B2702A0040



Shaft

Part Code: B2803P0132



Spring

Part Code: B2810P0021



Part Code: RPA000007B/APA000007B



(GUIDE CASH FEED 5 ASS'Y) / (B1604A0242).



Part Code:	Parts List and Quantity	
B1604P0088	(CASH FEED 5 / GUIDE (o)	1шт.
B1108P0085	Mount	6шт.
B2702A0040	Roller	6шт.
B2803P0132	Shaft	6шт.
B2810P0021	Spring	12шт.
	Skrew M2.6x6	12шт.

CASH FEED 5

Part Code: B1604P0088



Mount

Part Code: B1108P0085



Part Code: B2702A0040



Part Code: B2803P0132



Part Code: B2810P0021



GUIDE CASH FEED 3 ASS'Y (Upper) / (B1604P0086).



Part Code:	Parts List and Quantity	
B2803P0127	Shaft	2шт.
B1604P0086	CASH FEED 3 / GUIDE (n)	7шт.
	Clamp (E-RING ϕ 4 (BK)	28шт.

CASH FEED 3

Part Code: B1604P0086



Clamp

Part Code: E-RING ϕ 4 (BK)



Направляющая 6 в сборе (GUIDE CASH FEED 6 ASS'Y) / (B1604P0088).



Part Code:	Parts List and Quantity	
B2803P0126	Shaft	2шт.
B1604P0087	(GUIDE CASH FEED 6 / GUIDE (p)	5шт.
	Clamp (E-RING ϕ 4 (BK))	20шт.

(GUIDE CASH FEED 6

Part Code: B1604P0087



Clamp

Part Code: E-RING ϕ 4 (BK)



SHAFT DIVERTER ASS'Y / B2803P0124.



Part Code:	Parts List and Quantity	
B2803P0124	SHAFT DIVERTER ASS'Y	1
B1604P0090	GUIDE DIVERTER	6
B1604P0091	GUIDE DIVERTER 2	2
	Screw M3x8	8

GUIDE DIVERTER

Part Code: B1604P0090



GUIDE DIVERTER 2

Part Code: B1604P0091



SHAFT SPACE CONNECTION ASS'Y / (B2803P0140).




Part Code:	Parts List and Quantity	
B2803P0140	SHAFT SPACE CONNECTION	1
4470-E0621A	GEAR DFDM DRIVE (Z:27, M:1) (G2)	5
	Screw M2.6x10	1

GEAR DFDM DRIVE

Part Code: 4470-E0621A(G2)



SHAFT PICK-UP ROLLER ASS'Y.



Part Code:	Parts List and Quantity	
B2803A0157	SHAFT ASSY PICK-UP ROLLER (a)	1
	CABLE ASSY CLUTCH	1
	CLAMP (E-RING ϕ 6(BK))	2
R1205P0002	CLUTCH	1

ROLLER (a)

Part Code: B2803A0157



CLAMP(E-RING ϕ 6(BK))

Part Code: E-RING ϕ 6(BK) (E)



CLUTCH

Part Code: R1205P0002



SHAFT HINGE D/D ASS'Y.



Part Code:	Parts List and Quantity	
B2803P0136	SHAFT HINGE D/D	1
B1004P0008	ARM D/D HINGE	1
B1101P0002	BEARING R1240ZZ	1
3300BP4162B	PLATE SPRING CLEAN BEARING	1
	CLAMP (E-RING ϕ 3(BK))	1
	SKREW(1W) M3x8	1
	SKREW(2W) M3x6	1

CASH BOX LEVER ASS'Y + BRACKET NEAREND ASS'Y

LEVER NEAREND SENSOR

Part Code: assembled



LEVER NEAREND SENSOR

Part Code: assembled



Part Code:	Parts List and Quantity	
B2104P0021	LEVER NEAREND SENSOR	1
B2104P0025	LEVER CASSETTE SENSOR	1
B2803P0138	SHAFT NEAREND 2	1
B2803P0137	SHAFT NEAREND 1	1
5740-E1001A	WASHER LOCK CDM	2
	Clamp (E-RING ϕ 4 (BK))	2
B2810P0031	SPRING NEAREND SENSOR	1

SUPPORTER CB/RB FIX ASS'Y/B2804P0016.



Part Code:	Parts List and Quantity	
B2804P0016		1
B1113P0001	BALL CATCH TL-60-1	2
B2201P0001	MAGNET TL-295	1
	CLAMP (1W) M3x8	4
B1212A0036	CABLE LIMIT SWITCH	1
	SCREW (1W) M3x8	2
B1108P0001	BRACKET SWITCH	1
	SCREW (2W) M3x6	1


BALL CATCH TL-60-1)

Part Code: B1113P0001



MAGNET TL-295)

Part Code: B1113P0001



Механизм соленоида в сборе.




SENSIS
RUSK COMPANY

Part Code:	Parts List and Quantity	
B2806P0020	SOLENOID 1040 JUWON	1
B2105P0013	LINK DIVERTER	1
	SKREW (1W) M3x12	1
	SOLENOID PLUNGER ASS'Y	1
5300-E0971A	SPRING SOLENOID STAMP)	1
	CLAMP (E-RING ϕ 2 (BK)	1

SOLENOID

Part Code: B2806P0020



SENSIS
RUSK COMPANY

SPRING

Part Code: 5300-E0971A



SENSIS
RUSK COMPANY

CLAMP

Part Code: E-RING ϕ 2 (BK)



SENSIS
RUSK COMPANY

SOLENOID PLUNGER.



SENSIS
RUSK COMPANY

Part Code:	Parts List and Quantity	
B2806P0004	SOLENOID PLUNGER)	1
4520-E0171A	LINK SOLENOID STAMP)	1
4370-E2211A	SHAFT SOLENOID PIN)	1
	CLAMP E-RING ϕ 2 (BK))	2

SOLENOID PLUNGER

Part Code: B2806P0004



SENSIS
RUSK COMPANY

SHAFT

Part Code: 4370-E2211A



SENSIS
RUSK COMPANY

CLAMP

Part Code: E-RING ϕ 2 (BK)



SENSIS
RUSK COMPANY

RVDT segment (LP06M3R).



Part Code:	Parts List and Quantity	
R1212A0050	RVDT segment (LP06M3R)	1
	BRACKET D/D HINGE	1

RVDT segment (LP06M3R)

Part Code: R1212A0050




BRACKET

Part Code:



BRACKET D/D HINGE



Part Code:	Parts List and Quantity	
B1108P0089	BRACKET D/D HINGE	1
B2803P0139	SHAFT D/D PUSH	1
	SKREW M3x4	1

BRACKET

Part Code: B1108P0089



LEVER D/D HINGE (7).



Part Code:	Parts List and Quantity	
B2104P0022	LEVER D/D HINGE (7)	1
B2503P0029	PLATE D/D SENSOR)	1
	SCREW (2W) M3x6	1

PLATE

Part Code: B2503P0029



LEVER D/D HINGE (7) Part

Code: B2104P0022




MAIN LCDM-2000) / Part Code: RPA000008B.



Parts list LCDM-2000.



ROLLER ASSY TENSION BELT
B2702A0041




BUSH 1480
B1111P0014



BUSH 860 OMR
B1111P0012



KNOB MANUAL FEED
4940BM3042



WHEEL ENCODER
4660BP4002A



LCDM SENSOR PCB EMIT /
PWA , EMIT J31
RPA000006B
APA000006B



GUIDE RB SLIDE L
B1604P0093



GUIDE RB SLIDE R
B160490094



BRKT SENSOR EXIT
B1108P0086




WHEEL SENSOR / CABLE ASSY
LCDM 4000 R1212A0055



BRUSH / LCDM-1000
B1110P0002



BEARING NMB LF1480ZZ



BUSHING BEARING
B1111P0021